POTTERYBARN

INDRA WOVEN EXTRA LARGE PENDANT Assembly Instructions

CAUTION:

• BEFORE INSTALLING FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

IMPORTANT SAFETY INSTRUCTIONS:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- We strongly recommend that a professional electrician install all direct wire fixtures.
- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- The lighting fixture is meant for indoor use. It must be connected only to 3-wire, single-phase electrical supply systems (provided with Ground wire or equivalent protection system).
- For your safety, it is strongly recommended that two people install the lighting fixture.
- This fixture has been rated for up to one (1) **60-watt maximum TYPE A standard incandescent light bulb** (not included) or one (1) **13-watt compact fluorescent light bulb** (not included). To avoid the risk of fire, do not exceed the recommended lamp wattage.
- The lighting fixture is meant for indoor use, DRY LOCATIONS ONLY.
- Save these instructions.

WARNING:


- To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- · Keep flammable materials away from lit bulb.
- This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth
 defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise
 touching this light fixture.

PRE-ASSEMBLY:


- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- For your safety and convenience, assembly by two people is recommended.


• Tools Required: (not included): Step Ladder, Electrical Tape, Philips Head Screwdriver, Wire Cutters/Stripper & Pliers













Parts Included:


- (E) Mounting disc/Bracket(1)
- (D) Canopy (1)
- (G) Socket (1)
- (H) Lamp Shade (1)
- (I) Shade Ring (1)

Hardware Enclosed:

- (F) Plastic Wire Nut Connectors (3)
- (A) Mounting Screws (2)
- (B) Canopy Screws (2)
- (J) Green Ground screw (1)









ASSEMBLY & INSTALLATION INSTRUCTIONS:


- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
- 2. Carefully unpack all fixture parts and hardware and lay out on a clear workspace.




 Drill two holes on the ceiling to insert plastic corks (C). Install the the mounting disc/bracket (E) to junction box using mounting screws (A).



4. Please read the section" To Make the Wire Connections" Below.



5. Attach the Canopy (D) to the mounting disc/bracket (E) using the Canopy Screws (B). Use a screwdriver to tighten each screw until the Canopy is firmly secure.




- 6. Attach Lamp Shade (H) to Socket (G) and secure by locking with shade ring (I).
- 7. Insert one (1) 60 Watt maximum TYPE A standard incandescent light bulb (not included) or one (1) 13 Watt compact fluorescent light bulb (not included) into socket (G). DO NOT EXCEED THE SPECIFIED WATTAGE.

- Restore power to junction box and test fixture.
- Assembly and installation is complete.

To Make the Wire Connections:

- Gently pull existing wire down from the ceiling junction box and allow wires to hang. The HOT or LIVE wire is
 usually black. The NEUTRAL wire is usually white. Check to see if there is a ground wire that is usually green or
 green with a yellow stripe or exposed copper metal wire. If needed, use a pair of wire strippers to remove about
 1/2 inch of insulation from each wire.
- 2. Carefully inspect the fixtures wires. The NEUTRAL FIXTURE WIRE has FINE LONGITUDINAL RIDGES running along its length. The HOT FIXTURE WIRE is SMOOTH and the BARE COPPER WIRE is the GROUND WIRE. If you have any doubt and cannot identify the power-supply wires with confidence, then we recommend that you ask an electrician and that you not continue with the installation.
- 3. With the help of another person to hold the weight of the fixture, attach the fixture wires to the junction box wires as shown in the illustrations.



Connect the GROUND FIXTURE WIRE to the GROUND J-BOX WIRE using the Plastic Wire Nut Connector (F) and wrap the connection with electrical tape. Be sure that no wire strands are exposed.

If the junction box DOES NOT have a GROUND WIRE, wrap the fixture's bare ground wire around the Green Ground Screw (J) and insert the screw into the Mounting disc/bracket (E), marked as "GND", and tighten screw to secure the wire.

Connect the NEUTRAL FIXTURE WIRE to the NEUTRAL J-BOX WIRE first and then connect the HOT FIXTURE WIRE to the HOT J-BOX WIRE using the Plastic Wire Nut Connectors (F). Wrap these connections with electrical tape. Be sure that no wire strands are exposed.

US/CN

NOTE:

IT IS IMPERATIVE THAT THE JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED! DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

4. Check the wiring connections and if all looks good, gently tuck the wire connections neatly into the ceiling junction box.

Care instructions:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

Thank you for your purchase Stores | catalog | www.potterybarn.com USA 1.888.779.5176